


Upgrading firmware

Find the latest firmware version from the Transcend website :

<https://www.transcend-info.com/support/service>

Note: To prevent data loss, it is recommended that you backup your data to another location before upgrading the firmware of your DrivePro 50.

1. After downloading the firmware from Transcend's website, decompress it on your PC, and then drag the "**FWDP50.bin**" file to the root directory of your memory card. Make sure it is not in any folders.



2. Insert the microSD memory card that contains the latest firmware into your DrivePro 50.
3. Power on the DrivePro (by connecting it to power). The firmware upgrade will start automatically.
Do NOT remove the USB cable while the firmware is being upgraded.